



Music Equipment Set Up



Follow this step by step guide on how to set up the music equipment for your store.



Music should have been set up by the general contractor. If it has **not** been set up, please follow this guide.

1 Start by unboxing your Crown Amplifier.



2 On the **back** of the amplifier you will see the output is covered by a metal plate. Use a screwdriver to **remove** the plate. The plate can be discarded.



3 Remove the clear plate from the amplifier and **plug** in the power cable. Plug the power cable into the surge protector.




4 **Locate** your speaker wire which should have a red and black end to the cabling. >>




5 On the **back** of the amplifier there are 4 screws with plates.

- A** Slightly unscrew **70V**.
 - Insert the copper end of the **red** part of the speaker wire in 70V.
- B** Slightly unscrew **COM**.
 - Insert the copper end of the **black** part of the speaker wire in COM.
- C** Screw **both** plates shut.



6 **Gather** the music player package. **Unbox** the Mood Music player, the audio cable, and the power supply. >>





7 **A** **Plug** the power supply into the surge protector. **Plug** the other end into the back of the Mood Music player. >>




C **Plug** the white and red ends of the audio cable into Input 3 on the back of the amplifier. >>

B **Plug** the audio cable into the back port labeled AV. >>



- 8** On the front of the Mood Music player you will see **3 green lights**. 
- If you **DO NOT**, please contact IT.
 - IT Hotline (888) 397-0150 or Erik Hild (913) 348-4424



- 9** Turn on the amplifier. 
- Turn the **volume** for Input 3 and the Master volume (far right) up to 10.
 - **Check** to see if the front of your amplifier looks like the below photo.



If your amplifier looks like this, but you do **not** hear music playing in the store, please contact IT:

- IT Hotline (888) 397-0150 or Erik Hild (913) 348-4424